



When installing the Spike Power Sports upper door kit for the Yamaha RMAX-4, the shroud clips (referenced on page 9, step #2 of the instructions) will not be used. The shroud will be held in place by the left and right support pillars which are included with the OEM glass windshield kit.

If the OEM glass windshield is already installed, follow the steps below.

1. Loosen the left and right windshield support pillars.
2. Feed the door shroud tabs between the windshield support pillars and the vehicles roll cage.
3. Re-tighten the windshield support pillars. This will secure the door shroud securely to the vehicle.

